

RENAULT CLIO IMMOILISER BYPASS

The Renault immobiliser bypass device need to be plugged into the socket under the ashtray as shown below



Remove the cover from the socket



Plug bypass device into the socket

NOTE: A small cut out location slot is on the device, it will only fit one way



Turn ignition on, WAIT until dashboard red flashing LED light goes out, this takes about 4 seconds, car will now start.

NOTE: Once car is started Red LED light will come back on for about 30 seconds, this is normal

The ashtray can be put back into position.

ANY PROBLEMS PLEASE email mail@remotekey.co.uk

Thank you for using Remote Key Ltd

GUARANTEE

This product is guaranteed for a period of 12 months against faulty materials and workmanship.

Whilst every possible care is taken by Remote Key Ltd to ensure our products leave in good working order, Remote Key Ltd cannot under any circumstances accept liability for problems or damage caused by their subsequent use.

This guarantee does not affect your statutory rights.

Thank you.

IF YOUR CAR WILL NOT START

1. Check the vehicles battery is fully charged (does the engine turnover OK?)
2. Check all the fuses, under the bonnet far left passenger side corner & at the end of the dashboard.
3. Look at the bypass, turn on the ignition the bypass will flash a blue LED light, if this light does not flash it has no power, check wiring connections battery condition and fuses.
4. If the blue LED light flashes fast the bypass cannot connect to the car, check the connections behind the bonnet release pull leaver under the dashboard on the passenger side.
5. If the blue LED light flashes / pauses / flashes / pauses the bypass is working but the code is wrong, check the code from your key or service book is correct "6" & "G" & "2" & "Z" can be easily mixed up, if you have the wrong code send the bypass back with your key and we will check it for you.